

PATCH IT™ INSTRUCTIONS

Using metal buffer, clean an area around the puncture in the tube slightly larger than the patch.

1. Apply thin coat of cement to cleaned area of tube and allow to dry.
2. Peel plastic backing off patch and apply to tube. Be careful not to touch either the cleaned area on the tube or the adhesive side of the patch
3. Working from center of patch outward, press air out from under patch.
4. Tube is now ready to reinstall.

WARNING! Inflate tire to recommended tire pressure. Under inflated or over inflated tires can result in an accident resulting in serious injury or death.